adon®

4.2P SP

HIGH FIDELITY ACTIVE SPEAKER

快速入门指南
Quick start guide

请先读我
Please read me first

adon®

4.2P SP 202406 01C
Copyright © 2024 Foshan Maosheng Electronics Co., Ltd. All Rights Reserved.

欢迎
Welcome

谢谢您选购adon高保真有源音箱。
本指南为您设定提供逐步说明。

Thank you for purchasing the adon high fidelity active speakers.
This guide provides step-by-step instructions for you to set up.

开始之前
Before the start

包装盒中物品清单
List of items in the box

使用指南 User guide	音箱 Speakers
音箱脚垫 Speaker foot pads	电源 Power supply
主副音箱连接线 Main and secondary speaker connection cable	电源线 Power cable

基本连接所需物品
Items required for basic connection

音箱 Speakers	主副音箱连接线 Main and secondary speaker connection cable	电源线 Power cable	电源 Power supply

- 请注意，本手册中的插图为示意图，可能与实物有差异。
- Please note that the illustrations in this manual are schematic diagrams and may differ from the actual product.

设定步骤
Setup steps

设定过程包括四个步骤。
The setup process includes four steps.

1. 主副音箱连接线连接主、副音箱
   Connect the main and secondary speaker connection cable to the main and secondary speakers
2. 电源输出线连接到主音箱
   Connect the Power supply output line to the main speaker
3. 电源线连接到电源中
   Connect the power cable to the Power supply
4. 打开电源开关，开始使用
   Turn on the power switch and start using

粘贴音箱脚垫到音箱的底部
Attach the speaker foot pads to the bottom of the speaker



1 主副音箱连接线连接主、副音箱
Connect the main and secondary speaker connection cable to the main and secondary speakers



副音箱　　主音箱



• 可与低音炮、电脑、电视机、手机、平板电脑及电唱机的连接。
It can be connected with subwoofer, computer, TV, mobile phone, tablet computer and PHONO.

2 电源输出线连接到主音箱

Connect the Power supply output line to the main speaker



3 电源线连接到电源中

Connect the power cable to the Power supply



电源线插入电源插座

Plug the power cord into a power outlet



4 打开电源开关，开始使用

Turn on the power switch and start using



1 短按INPUT/VOLUME选择音频通道。
Press the INPUT/VOLUME button to select an audio channel.

同时指示灯对应各通道状态
The indicators correspond to the status of each channel

AUX通道:●红，电唱机通道:●黄(MM) ●绿(MC)，蓝牙通道:●蓝
AUX channel: red, PHONO channel: yellow(MM) green(MC)，
Bluetooth channel: blue

2 旋转INPUT/VOLUME调整音量。
Rotate INPUT/VOLUME to adjust the volume.

• [请参考使用指南以了解有关音箱及其功能设置和操作的更多信息]
Please refer to the user guide for more information about the speakers and its function settings and operation.

使用应用程序轻松进行操作

Easy operation with the app

1 启用您的移动设备上的蓝牙设定，与“4.2P SP”进行配对。
Enable Bluetooth Settings on your mobile device to pair with "4.2P SP".

2 启动您的移动设备上的 4.2P SP App。
Launch the 4.2P SP App on your mobile device.

3 对音箱进行操作。
Operate the speaker.

[相关信息]
[Relevant information]

- Mute 静音选择 Mute selection
- Input 输入选择 Input selection
- Volume 音量调整 Volume adjustment
- Bluetooth 蓝牙设定 Bluetooth settings
- Settings 通用设定 General settings
- Equal Loudness 等响度设定 Equal loudness settings
- Bass Volume 低音设定 Bass settings
- EQ 均衡设定 EQ settings

获取 4.2P SP App

Obtain 4.2P SP App

根据您所处的地理位置，可提供几种选择。
Depending on your geographic location, there are several options available.

Download on the App Store

iOS Android

• 为提高可用性，4.2P SP App的规格可能会更改，恕不另行通知。