adon®

4.2P SP

HIGH FIDELITY ACTIVE SPEAKER

快速入門指南
Quick start guide

請先讀我
Please read me first

adon®

4.2P SP 202406 01C

Copyright © 2024 Foshan Maosheng Electronics Co., Ltd. All Rights Reserved.

歡迎
Welcome

謝謝您選購adon高保真有源音箱。
本指南為您設定提供逐步說明。

Thank you for purchasing the adon high fidelity active speakers.
This guide provides step-by-step instructions for you to set up.

開始之前
Before the start

包裝盒中物品清單
List of items in the box

使用指南 User guide	音箱 Speakers
音箱腳墊 Speaker foot pads	電源 Power supply
主副音箱連接線 Main and secondary speaker connection cable	電源線 Power cable

基本連接所需物品
Items required for basic connection

音箱 Speakers	主副音箱連接線 Main and secondary speaker connection cable	電源線 Power cable	電源 Power supply

- 請注意，本手册中的插圖為示意圖，可能與實物有差异。
- Please note that the illustrations in this manual are schematic diagrams and may differ from the actual product.

設定步驟
Setup steps

設定過程包括四個步驟。
The setup process includes four steps.

1. 主副音箱連接線連接主、副音箱
   Connect the main and secondary speaker connection cable to the main and secondary speakers
2. 電源輸出線連接到主音箱
   Connect the Power supply output line to the main speaker
3. 電源線連接到電源中
   Connect the power cable to the Power supply
4. 打開電源開關，開始使用
   Turn on the power switch and start using

貼上音箱腳墊到音箱的底部
Attach the speaker foot pads to the bottom of the speaker



1 主副音箱連接線連接主、副音箱
Connect the main and secondary speaker connection cable to the main and secondary speakers



副音箱　　主音箱



• 可與低音炮、電腦、電視機、手機、平板電腦及電唱機的連接。
It can be connected with subwoofer, computer, TV, mobile phone, tablet computer and PHONO.

2 電源輸出線連接到主音箱

Connect the Power supply output line to the main speaker



3 電源線連接到電源中

Connect the power cable to the Power supply



電源線插入電源插座

Plug the power cord into a power outlet



4 打開電源開關，開始使用

Turn on the power switch and start using



1 短按INPUT/VOLUME選擇音訊通道。
Press the INPUT/VOLUME button to select an audio channel.

同時指示燈對應各通道狀態
The indicators correspond to the status of each channel

AUX通道:●紅，電唱機通道:●黃(MM) ●綠(MC)，藍牙通道:●藍
AUX channel: red, PHONO channel: yellow(MM) green(MC)，
Bluetooth channel: blue

2 旋轉INPUT/VOLUME調整音量。
Rotate INPUT/VOLUME to adjust the volume.

• [請參考使用指南以瞭解有關音箱及其功能設置和操作的更多資訊]
Please refer to the user guide for more information about the speakers and its function settings and operation.

使用應用程序輕鬆進行操作

Easy operation with the app

獲取 4.2P SP App

Obtain 4.2P SP App

根據您所處的地理位置，可提供幾種選擇。
Depending on your geographic location, there are several options available.

adon 4.2P SP | Download on the App Store

iOS | Android

• 為提高可用性，4.2P SP App的規格可能會更改，恕不另行通知。

1 啟用您的移動設備上的藍牙設定，與“4.2P SP”進行配對。
Enable Bluetooth Settings on your mobile device to pair with "4.2P SP".

2 啟動您的移動設備上的 4.2P SP App。
Launch the 4.2P SP App on your mobile device.

3 對音箱進行操作。
Operate the speaker.

[相關資訊]
[Relevant information]

- Mute 靜音選擇 Mute selection
- Input 輸入選擇 Input selection
- Volume 音量調整 Volume adjustment
- Bluetooth 藍牙設定 Bluetooth settings
- Settings 通用設定 General settings
- Equal Loudness 等響度設定 Equal loudness settings
- Bass Volume 低音設定 Bass settings
- EQ 均衡設定 EQ settings